



LiFe and Eco Series Battery Settings for Solis Inverters

OVERVIEW

Settings listed are only applicable to battery charge and discharge. All other settings are the responsibility of the integrator.

It is the responsibility of the integrator to have a full understanding of the connected PCE prior to programming, and it is preferred that they have attended the manufacturer’s training or integration course should they be available.

SoC Drift

State of Charge (“Soc”) drift happens when the product that is calculating SoC builds up an accumulative error. This error is generally due to tolerance of components that measure voltage and current, and algorithms used to calculate the SoC. Most products will reset its accumulative error when the system gets to 100% SoC or Float.

It is important that a well-designed battery storage system reaches Float stage as regularly as possible, preferably every one to two days to rest SoC drift.

SoC drift can be addressed in many ways.

Examples:

1. Sufficient solar sized to charge batteries to float on the winter equinox
2. Backup source installed (grid or generator) to allow charging of batteries during extended bad weather or high load events.

How many batteries do I need?

Minimum battery size should be greater than the rated peak output of the inverter.

Battery to PV ratio is no less than 2.5kWh (battery) : 1kw (PV).

The battery quantity is not compulsory, however it’s highly recommended as a minimum to reduce possible battery trips due to over current.

Always consult and read the manufactures documentation before designing, installing and programming their devices.

Recommended Minimum Battery Modules

	LiFe4833P	LiFe4838P	Eco4840P
Solis S5-EH1P-L Hybrid Inverter	3	3	4
Solis S6-EH1P5K-L-AU Hybrid Inverter	3	3	4

Battery Settings for Inverters

	LiFe4833P	LiFe4838P	Eco4840P
Battery Type	Lead Acid Battery		
Battery capacity	Total Ah Capacity of PowerPlus Energy Battery Bank Installed		
Floating voltage	57.6V	56.9V	57.6V
I_Max Discharge	Max. 63A per battery installed	Max. 63A per battery installed	Max. 39A per battery installed
I_Max Charge	Max 32A per battery installed	Max. 39A per battery installed	Max. 39A per battery installed
Equalizing Voltage	57.6V	56.9V	57.6V
Overdischg Voltage	50.2V		
Force Charge Voltage	48V		
ForceChg PLmt	Max. 1600W per battery installed	Max. 2000W per battery installed	Max. 2000W per battery installed
Temp. Compensation	0		
AMB. Temp.Lower	5°		
AMB.Temp.Upper	45°		
Power Limit On	From Grid		
Save and Send			
Environment Temp	Warm		

Installers should ensure an adequate system design is carried out at all times. PPE accepts no responsibility for underperforming system designs. As part of our continued improvement process, settings are subject to change without notice and are correct at time of publishing.